



Single Ceramic Contact Grill
Smooth & Ribbed
CCG1S & CCG1R Operating Manual

Introduction

Thank you for purchasing a Pantheon Catering Equipment product. In this booklet you will find instructions for safe operation so please read carefully and retain for future reference.

Warnings and Precautions

The following warnings and precautions are important and must be observed:

- Ensure voltage and frequency power requirements for the contact grill match that of the supply.
- The machine must be earthed when used. There is a danger of electric shock if it is not earthed.
- In case of emergency, please turn off the power switch and unplug the machine.
- If the electric wire becomes damaged, a qualified engineer or the manufacturer must replace it.
- Never place any plastic products or packaging on the device as they may melt and cause damage to the grill.

Pantheon Catering Equipment is not responsible for any accidents or faults caused by amendments made to the machine or improper use by the user.

Technical Data

Specifications:

Model:	CCG1S	CCG1R
Voltage (V)	220-240V 50Hz	220-240V 50Hz
Power (W)	1600	1600
Weight (Kg)	10	10
Heating Zone (mm)	250x250	250x250
Dimensions (mm)	340w x 480d x 170h	340w x 480d x 170h

Installation

The installation of the unit must be performed by a qualified technician only.

Place the device on top of a solid, even, safe and stable surface that tolerates the weight of the unit.

Ensure no flammable products are placed near the unit, as it will get hot.

Position the device appropriately so that the plug is always accessible. Also ensure the unit isn't placed close to any water.

Operating Instructions

Sandwich Cooking:

Ceramic glass is not porous like the metal contact grills, so will not absorb or transfer flavours. They are perfect for cooking sandwiches. Follow the instructions below for cooking sandwiches:

1. Turn the contact grill on and set the desired temperature
2. The Contact Grill preheats in just minutes. You will notice the temperature light illuminates, indicating that power is going to the grill. Your grill will be preheated and ready to start cooking in about 2 or 3 minutes. When the power light is no longer illuminated, the grill is ready to use.
3. Sandwiches will usually take between 2 – 5 minutes to heat throughout. The cooking time depends upon the bread you use and the ingredients you have chosen for your sandwich.
4. Most of your Panini sandwiches will be grilled at temperatures between 250°C and 280°C.
5. Light pressure is all you need when lowering the top grill to assure a perfectly cooked sandwich. Excessive pressure will not speed up the cooking process.
6. To keep your grill clean between sandwiches, simply wipe the grill surfaces with a clean oiled paper towel.

Maintenance

Cleaning:

Before cleaning, please ensure the unit is turned off and disconnected from the mains.

The Contact Grill may be “Quick Cleaned” with the scraper provided. The residue may be emptied into the drip tray under the grill through the opening at the front of the Contact Grill. Be sure to clean the drip tray regularly to avoid spills.

For hard to clean spots use the scraper or the metal scrub pad.


There are many nonabrasive cleaners specifically made for ceramic cooking tops on the market today. We suggest using your choice of nonabrasive cleaner at the end of each day or service period to keep your Contact Grill in top condition.

Never use a spray of water or immerse the grill in water. This will damage the electrical components and might create a hazardous condition.


Troubleshooting

Problem	Possible Causes	Solutions
Module plates do not heat up when the power and the heating indicator are both on	1. Temperature controller is broken. 2. The heating element has blown. 3. The high temperature cut-out has activated.	1. Replace the temperature controller. 2. Replace the heating element. 3. Press the reset button
The temperature of the grill cannot be controlled	The temperature controller is broken	Replace the temperature controller
The power indicator doesn't illuminate and the unit won't heat up	1. Check the unit is plugged in securely 2. Fuse may have blown	If the fuse has blown replace it

Circuit Diagrams



Parts Diagrams



Parts List

NO.	Name	Spec.	pcs	Note
1	Handle		1	
2	Top-body	SUS430	1	
3	Bottom-body	SUS430	1	
4	Bottom cover	Al-coating	1	
5	Back cover	SUS430	1	
6	Spring		1	
7	Copper block	copper	1	
8	Long screw	black,tough	2	
9	Power cord and plug		1	
10	Heater	800W/230V	2	
11	Lamp		2	
12	Thermostat		1	
13	Knob base		1	
14	Knob		1	
15	Ceramic glass	4mm	2	FC-1:2 flat glass FC-1A:top groove glass and bottom flat glass
16	Feet		4	
17	Oil tray	SUS430	1	
18	Handle fixer		2	
19	Handle fixer screw		2	
20	Rotate-role		1	
21	Rotate-role-screw		2	
22	Right-support	SUS430	1	
23	Left-support	SUS430	1	