

Machine	Machine Waring Code	Exploded No.	Nisbets Code	Description	Stocked
T447	BB185SK	1	WA320	Cover Lid	✓
T447	BB185SK	2	WA319	Jar Lid	✓
T447	BB185SK	3	WA318	Jar 44 oz	✓
T447	BB185SK	4	WA322	Jar Seal	✓
T447	BB185SK	5	N915	Blending A	✓
T447	BB185SK	6	WA323	Jar Bottom	✓
T447	BB185SK	7	WA409	Blade & Sh	✓
T447	BB185SK	8	WA343	V Seal	✓
T447	BB185SK	9	WA344	Bearing Hd	✓
T447	BB185SK	10	WA345	Washer	✓
T447	BB185SK	11	WA316	Clutch	✓
T447	BB185SK	12	WA348	Jar Cover	✓
T447	BB185SK	13	WA347	Jar 32oz	✓
T447	BB185SK	14	WA316	Clutch	✓
T447	BB185SK	15	WA032	Washer	✓
T447	BB185SK	16	WA313	Top Housin	✓
T447	BB185SK	17	n/a	Control Mo	n/a
T447	BB185SK	18	n/a	Screw	n/a
T447	BB185SK	19	WA315	Upper Mot	✓
T447	BB185SK	20	WA346	Rubber Bu	✓
T447	BB185SK	21	WA336	Eyelet	✓
T447	BB185SK	22	WA337	Screw	✓
T447	BB185SK	23	n/a	ECM Moto	n/a
T447	BB185SK	24	n/a	Shroud	n/a
T447	BB185SK	24	WA332	Shroud (O)	✓
T447	BB185SK	25	WA404	Resistor As	✓
T447	BB185SK	26	n/a	Lead Asse	n/a
T447	BB185SK	26	n/a	Lead Asse	n/a
T447	BB185SK	27	n/a	Lead Asse	n/a
T447	BB185SK	28	n/a	Lead Asse	n/a
T447	BB185SK	29	WA403	Filter Asse	✓
T447	BB185SK	30	n/a	Crimp Con	n/a
T447	BB185SK	31	WA105	Cable Tie	✓
T447	BB185SK	32	WA002	Screw	✓
T447	BB185SK	33	WA010	Lock Wash	✓
T447	BB185SK	34	WA297	Reset Swit	✓
T447	BB185SK	35	n/a	Strian Reli	n/a
T447	BB185SK	36	n/a	Cord Set	n/a
T447	BB185SK	36	WA415	Cord Set	✓
T447	BB185SK	36	n/a	Cord Set	n/a
T447	BB185SK	37	n/a	Bottom Ho	n/a
T447	BB185SK	37	n/a	Bottom Ho	n/a
T447	BB185SK	37	n/a	Bottom Ho	n/a
T447	BB185SK	37	n/a	Bottom Ho	n/a
T447	BB185SK	38	WA341	Screw Tam	✓
T447	BB185SK	38	n/a	Screw	n/a
T447	BB185SK	39	WA317	Suction Cu	✓
T447	BB185SK	40	WA117	Washer	✓
T447	BB185SK	41	WA142	Hex Nut	✓
T447	BB185SK	42	n/a	Bottom Pla	n/a
T447	BB185SK	n/a	WA340	Caution La	✓