



User and Installation Instructions

Lynx 400 Electric Bains Marie

LBM, LBMW, LBM2, LBM2W, LBM3,
LBM3W, LRB, LRBW, LRB2W, LRB3,
LRB3W

Please make a note of your product details for future use:

Date Purchased: _____

Model Number: _____

Serial Number: _____

Dealer: _____

LYNX 400

Dear Customer,

Thank you for purchasing this **Lincat** Product.

This is just one of over 450 different items of catering equipment available from our range which is constantly being extended and improved. Details are available from your local distributor or direct from us.

Used for the purposes for which it is intended, and with careful maintenance as outlined in this user Guide, your **Lincat** product will give years of trouble free use.

IMPORTANT INFORMATION



Please read all of the safety and operating instructions carefully before using this product. Please pay particular attention to all sections of this User Guide that carry warning symbols and notices.



WARNING!

This is a Warning symbol. This symbol is used throughout the user guide whenever there is a risk of personal injury. Ensure that these warnings are read and understood at all times.



CAUTION!

This is a Caution symbol. This symbol is used throughout the User Guide whenever there is a risk damaging your Lincat product. Ensure that these warnings are read and understood at all times.

SAFETY INSTRUCTIONS



WARNING!

Basic safety precautions, including the following, should be followed to reduce the risk of personal injury. Make sure you have read all of these instructions before switching on the unit. Keep this User Guide in a safe place for future reference for you and your staff.

GENERAL

Do not clean the unit with a water jet.

Do not try to modify this product.

Remove all plastic coatings and clean the units before use.

Ensure that the electrical supply cable is not damaged. If the supply cable is damaged it should be replaced by Lincat Ltd or other suitably qualified persons, in order to avoid a hazard.

Disconnect the unit from the electric supply before servicing or undertaking any electrical maintenance.

This appliance must be earthed.

TECHNICAL SPECIFICATION

Model		LBM/LBMW	LBM2/LBM2W	LBM3/LBM3W
Width	mm	285	565	850
Depth	mm	400	400	400
Height (Max)	mm	196	196	196
Power Rating	Watt	250	500	750
Weight (net)	kg	6 / 7.5	10.5 / 13	14 / 17.5
Model		LRB/LRBW	LRB2/LRB2W	LRB3/LRB3W
Width	mm	285	565	850
Depth	mm	400	400	400
Height (Max)	mm	251	251	251
Power Rating	Watt	250	500	750
Weight (net)	kg	6 / 7.5	10 / 13	14 / 17

PACK CONTENTS

Electric bain marie (with cable and 13 amp plug)
User guide

Rubber feet x 4
Guarantee card

Specific accessories

Unit Code	
LBM	2 x ¼ gastronorms,
LBMW	2 x ¼ gastronorms, water tank
LBM2	4 x ¼ gastronorms, 2 x spacers
LBM2W	4 x ¼ gastronorms, 2 x spacers, water tank
LBM3	6 x ¼ gastronorms, 4 x spacers
LBM3W	6 x ¼ gastronorms, 4 x spacers, water tank
LRB	1 x 8pt pot, hobtop insert
LRBW	1 x 8pt pot, hobtop insert, water tank
LRB2	2 x 8pt pots, hobtop insert
LRB2W	2 x 8pt pots, hobtop insert, water tank
LRB3	3 x 8pt pots, hobtop insert
LRB3W	3 x 8pt pots, hobtop insert, water tank

INSTALLATION



Push rubber feet into base holes provided and ensure that the unit is installed on a sound, level work surface, which is heat resistant e.g. stainless steel or formica. Inform your personnel that the external surfaces and base will become hot.

For safety regulations, the plug must always be accessible.

CONNECTING TO THE ELECTRICITY SUPPLY



Ensure that the voltage of your electricity supply corresponds to the serial plate details. The product is supplied with a 13 amp plug. To replace the plug, follow these instructions:

- Green and yellow wire to 'E' or (Earth)
- Blue wire to 'N' (Neutral)
- Brown wire to 'L' (Live)

OPERATING INSTRUCTIONS




Fig 1 – Model LBMW

Fig 1 also represents the other bain marie models in the Lynx 400 range. Dry heat bains marie have no tank.

- 1 Green neon**
- 2 Control knob**
- 3 Level markers (Max / Min)**

Connect the unit to the electricity supply. The neon will light up. Turn the control knob to the desired temperature.

Wet well models: Fit the water tank, then turn on the unit and fill with water to a level between the minimum and maximum markers.

CLEANING AND MAINTENANCE

CLEANING



Disconnect the unit from the electricity supply and allow to cool before starting to clean. Use a mild detergent in hot water and a soft cloth. Do not use abrasive creams or scourers.

MAINTENANCE

Regular cleaning of the unit is recommended.

Regular maintenance is not required.

SERVICE INFORMATION

For help regarding the installation, maintenance and use of your **Lincat** equipment, please contact our service department :

 01522 875520

All service work, other than routine cleaning should be carried out by one of our authorised service agents. We cannot accept responsibility for work carried out by other persons.

To ensure your service enquiry is handled as efficiently as possible, you need to have the following details available :

- **Brief details of problem**
- **Product code, type number and serial number of unit (both on serial plate)**

Lincat reserve the right to carry out any work under warranty during normal working hours, ie Monday to Friday, 08:30 a.m. – 17:00 p.m.

GUARANTEE

This unit carries a comprehensive UK twelve-month warranty. The guarantee is in addition to , and does not diminish your statutory or legal rights.

The guarantee does not cover :

- Accidental damage, misuse (or use not in accordance with the instructions in this User Guide), or consumable items.
- Damage due to incorrect installation, modification or unauthorised service work.
- The manufacturer disclaims any liability for incidental, or consequential damages.