


For Machines with a Digital Timer

[Click here](#)

For Machines without a Digital Timer


[Click here](#)

For Machines with a Digital Timer



Machine	Explode	Code	Description
L518 - Contact Grill Large Ribbed/Ribbed with Timer	1		Top Cover
L518 - Contact Grill Large Ribbed/Ribbed with Timer	2	N482	main Handle
L518 - Contact Grill Large Ribbed/Ribbed with Timer	3		Mica Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	4		Rear Cover
L518 - Contact Grill Large Ribbed/Ribbed with Timer	5	N154	Heating Element Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	6		Cast Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	7		Cast Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	8		Hinge
L518 - Contact Grill Large Ribbed/Ribbed with Timer	9		Plate Connecting Spring
L518 - Contact Grill Large Ribbed/Ribbed with Timer	10	N155	Heating Element Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	11		Insulation Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	12	N126	Thermal Cut Out
L518 - Contact Grill Large Ribbed/Ribbed with Timer	13		Main Body
L518 - Contact Grill Large Ribbed/Ribbed with Timer	14		Plug & Lead
L518 - Contact Grill Large Ribbed/Ribbed with Timer	15		Ceramic Tube
L518 - Contact Grill Large Ribbed/Ribbed with Timer	16		Base Plate
L518 - Contact Grill Large Ribbed/Ribbed with Timer	17	AC689	Feet
L518 - Contact Grill Large Ribbed/Ribbed with Timer	18	N125	Thermostat
L518 - Contact Grill Large Ribbed/Ribbed with Timer	19	N129	Dial
L518 - Contact Grill Large Ribbed/Ribbed with Timer	20	N486	Indicator Light
L518 - Contact Grill Large Ribbed/Ribbed with Timer	21	N146	Switch
L518 - Contact Grill Large Ribbed/Ribbed with Timer	22	N478	Drip Tray
L518 - Contact Grill Large Ribbed/Ribbed with Timer	23		Mica Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	24	N484	Small Handle
L518 - Contact Grill Large Ribbed/Ribbed with Timer	25		Insulation Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	26	AD566	Tension Bracket
L518 - Contact Grill Large Ribbed/Ribbed with Timer	27	AE837	Timer with Transformer
L518 - Contact Grill Large Ribbed/Ribbed with Timer	Not shown	AD565	Wiring Loom

For machines without digital timer:



Machine	Explode	Code	Description
L518 - Contact Grill Large Ribbed/Ribbed	1		Top Cover
L518 - Contact Grill Large Ribbed/Ribbed	2	N482	main Handle
L518 - Contact Grill Large Ribbed/Ribbed	3		Mica Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed	4		Rear Spring
L518 - Contact Grill Large Ribbed/Ribbed	5	N154	Heating Element Upper
L518 - Contact Grill Large Ribbed/Ribbed	6		Cast Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed	7		Cast Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	8		Hinge
L518 - Contact Grill Large Ribbed/Ribbed	9	N480	Plate Connecting Spring
L518 - Contact Grill Large Ribbed/Ribbed	10	N155	Heating Element Lower
L518 - Contact Grill Large Ribbed/Ribbed	11		Insulation Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	12	N126	Thermal Cut Out
L518 - Contact Grill Large Ribbed/Ribbed	13		Main Body
L518 - Contact Grill Large Ribbed/Ribbed	14	N150	Plug & Lead
L518 - Contact Grill Large Ribbed/Ribbed	15		Ceramic Tube
L518 - Contact Grill Large Ribbed/Ribbed	16		Base Plate
L518 - Contact Grill Large Ribbed/Ribbed	17		Feet
L518 - Contact Grill Large Ribbed/Ribbed	18	N125	Thermostat
L518 - Contact Grill Large Ribbed/Ribbed	19	N129	Dial
L518 - Contact Grill Large Ribbed/Ribbed	20	N486	Indicator Light
L518 - Contact Grill Large Ribbed/Ribbed	21	N146	Switch
L518 - Contact Grill Large Ribbed/Ribbed	22	N478	Drip Tray
L518 - Contact Grill Large Ribbed/Ribbed	23		Mica Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	24	N484	Small Handle
L518 - Contact Grill Large Ribbed/Ribbed	25		Insulation Plate Upper