



User and Installation Instructions

Seal Ambient Merchandisers C6A/75, C6A/100

Please make a note of your product details for future use:

Date Purchased: _____

Model Number: _____

Serial Number: _____

Dealer: _____



Dear Customer,
Thank you for purchasing this Lincat product.

This is just one of over 450 different items of catering equipment available which is constantly being extended and improved. Details are available from your local distributor or direct from us.

Used for the purposes for which it is intended, and with careful maintenance as outlined in this User Guide, your **Lincat** product will give years of trouble free use.

IMPORTANT INFORMATION



Please read all of the safety and operating instructions carefully before using this product. Please pay particular attention to all sections of this User Guide that carry warning symbols and notices.



WARNING!

This is a Warning symbol. This symbol is used throughout the user guide whenever there is a risk of personal injury. Ensure that these warnings are read and understood at all times.



CAUTION!

This is a Caution symbol. This symbol is used throughout the User Guide whenever there is a risk damaging your Lincat product. Ensure that these warnings are read and understood at all times.



NOTE:

This is a Note symbol. This symbol is used throughout the User Guide to provide additional information, hints and tips.

CONTENTS

<i>Contents</i>	<i>Page</i>
Safety instructions	4
Product specification	4
Features	4
Technical specification	5
Pack contents	5
Spare parts list	5
Installation	6
<i>Connecting to the electricity supply</i>	6
Operating instructions	6
Cleaning and maintenance	7
<i>Replacing the light tube</i>	7
Service information	8
Conditions of guarantee	8

USE OF THE AMBIENT MERCHANDISERS

The Ambient Merchandisers are intended to be used on counter tops to display food products.

SAFETY INSTRUCTIONS



WARNING!

Basic safety precautions, including the following, should be followed to reduce the risk of personal injury. Make sure you have read all of these instructions before switching on the unit.

Keep this User Guide in a safe place for future reference for you and your staff.

Do not clean the unit with a water jet.

REMOVAL OF PACKAGING

In the interest of hygiene, you should clean the product after unpacking and ensure all plastic coatings are removed before use.

This unit is heavy. Take care when moving it. Do not pull the unit across your work surface as it is heavy and may make a mark.

GENERAL

Do not try to modify this product.

Ensure that the electrical supply cable is not damaged.

If the supply cable is damaged, it should be replaced by Lincat Ltd or suitably qualified persons, in order to avoid a hazard.

EQUIPOTENTIALITY



This equipment is provided with an equipotential bonding terminal to allow earth cross-bonding with other equipment.

PRODUCT SPECIFICATION

650 Range Ambient Merchandiser – C6A/75, C6A/100

FEATURES

**Extruded aluminium frame
Toughened glass (flat panels)
Sliding rear doors
Internal Illumination**

**Adjustable shelf positions (back service models only)
230 Volt, 50 Hz, single phase operation**

TECHNICAL SPECIFICATION

Model		C6A/75	C6A/100
Volume (gross)	litres	284.0	380.0
Internal Dimensions	mm	740x640x600	990x640x600
Width	mm	750	1000
Depth	mm	650	650
Height	mm	755	755
Power Rating	Watt	18	18
Weight (net)	kg	41.7	51.5

PACK CONTENTS

C6 Models

Ambient Merchandiser (with
 cable and 13amp plug)
 2 x chrome-plated shelves
 2 x front and rear base panels
 2 x sliding doors

3mm Allen key (for shelf
 adjustment)
 User Guide
 Guarantee card

SPARE PARTS LIST

Components	
Light Tube	BU171
Shelf (75 Models)	SH97
Shelf (100 Models)	SH98
Front Base Panel (75 Models)	BP28
Rear Base Panel (75 Models)	BP29
Front Base Panel (100 Models)	BP30
Rear Base Panel (100 Models)	BP31
Starter	GL68
Self Service Door Knob	S/M0085

INSTALLATION



Ensure the unit is installed on a sound, level work surface.



For safety regulations, the plug must always be accessible.

CONNECTING TO THE ELECTRICITY SUPPLY



Ensure that the voltage of your electricity supply corresponds to the serial plate details. The product is supplied with a 13 Amp plug. To replace the plug, follow these instructions:

- green and yellow wire to 'E' or (Earth)
- blue wire to 'N' (Neutral)
- brown wire to 'L' (Live)



THIS APPLIANCE MUST BE EARTHED

OPERATING INSTRUCTIONS

Ensure the base-plates lie flat within the base and the shelves are secure. Connect the unit to the electricity supply, and switch on the light using the green switch.

ADJUSTING THE SHELF POSITIONS



Disconnect from the electricity supply. Slide the doors to the middle position, lift up and out of the runners to remove. Lift and rotate all shelves to remove. An Allen key is provided to adjust the shelf supports. At the front, remove the two screws and replace in the appropriate holes. At the rear, the shelf support screws are situated behind the cable panel. Remove the screws in the cable panel first; carefully remove the panel to adjust the screw positions. Replace the panel ensuring that the cables are not trapped.

CLEANING AND MAINTENANCE

CLEANING



Disconnect the unit from the electricity supply before starting to clean. Use a mild detergent in hot water and a soft cloth. Do not use abrasive creams or scourers.

Remove the rear doors, shelves and base-plates. Brush the crumbs into the tray. Shelves (including supports) and base-plates may be washed in a dishwasher.

MAINTENANCE

Regular cleaning of the unit is recommended. No regular maintenance is required, but it may be necessary to replace a light tube.

REPLACING THE LIGHT TUBE



Disconnect the unit from the electricity supply and ensure the unit is cool to touch.

An Allen key is provided to remove the end caps from the light unit. Remove the diffuser from its clips. To remove the tube, carefully rotate it 90° and slowly pull down until it is released. It is recommended that the starter (a round cylinder located at one end of the tube) be also replaced at the same time. To remove the starter, rotate it anticlockwise. Fitting the new tube is the reverse of the above sequence.

SERVICE INFORMATION

For help regarding the installation, maintenance and use of your Lincat equipment, please contact our Service Department:

 **01522 875520**

All service work, other than routine cleaning should be carried out by one of our authorised service agents. We cannot accept responsibility for work carried out by other persons.

To ensure your call is service enquiry is handled as efficiently as possible, you need to have the following details available:

Brief details of problem

Product code, type number and serial number of unit (both on serial plate)

Code number of spare part (see spare parts list), if known

Lincat reserve the right to carry out any work under warranty during normal working hours, i.e. Monday to Friday, 8.30 a.m. – 5.00 p.m.

GUARANTEE

This unit carries a comprehensive UK twelve-month warranty. The guarantee is in addition to, and does not diminish your statutory or legal rights.

The guarantee does not cover: -

- Accidental damage, misuse (or use not in accordance with the instructions in this User Guide), or consumable items
- Damage due to incorrect installation, modification or unauthorised service work
- The manufacturer disclaims any liability for incidental, or consequential damages