





































Exploded diagram and spare parts list GL165-N/P GL166-N/P

Machine	Explode	Code	Description
Thor Freestanding Fryer	1		½ Connection
Thor Freestanding Fryer	2		Door Assembly
Thor Freestanding Fryer	3		Tube fix
Thor Freestanding Fryer	4		Oil Drainage
Thor Freestanding Fryer	5		G1/2 Elbow
Thor Freestanding Fryer	6		Inlet tube
Thor Freestanding Fryer	7		Burner Support Plate
Thor Freestanding Fryer	8		Fir Stop Panel
Thor Freestanding Fryer	9		Manifold
Thor Freestanding Fryer	10		Thor brand
Thor Freestanding Fryer	11		Control Panel
Thor Freestanding Fryer	12		Frame Insulation Plate
Thor Freestanding Fryer	13		Fram Top Piece
Thor Freestanding Fryer	14		Platform
Thor Freestanding Fryer	15		Frame Panel-L
Thor Freestanding Fryer	16	AF274	Valve
Thor Freestanding Fryer	17		Handle with Lock Ball Valve
Thor Freestanding Fryer	18	AF268	Burner
Thor Freestanding Fryer	19		Oil Tank Connect
Thor Freestanding Fryer	20		Oil Net
Thor Freestanding Fryer	21		Flame Device System (injector not included)
Thor Freestanding Fryer	21	AF276	ODS injector 0.01 (LPG)
Thor Freestanding Fryer	21	AF641	ODS injector 0.021 (Nat)
Thor Freestanding Fryer	22	AF270	Frying Basket
Thor Freestanding Fryer	23		Bulb Fix Up
Thor Freestanding Fryer	24		Pilot Support
Thor Freestanding Fryer	25		Flue Rear
Thor Freestanding Fryer	27		Oil Tank Weld Assembly
Thor Freestanding Fryer	28		Pilot Tube
Thor Freestanding Fryer	29		Orifice (Nat)
Thor Freestanding Fryer	29		Orifice (LPG)
Thor Freestanding Fryer	30		Inlet Pipe fitting
Thor Freestanding Fryer	32		Right Angle Elbow
Thor Freestanding Fryer	33		Frame Panel R
Thor Freestanding Fryer	34		Valve Connection
Thor Freestanding Fryer	35		Solenoid Valve Fix Plate
Thor Freestanding Fryer	36		Frame Bottom R
Thor Freestanding Fryer	37		Foot (optional)
Thor Freestanding Fryer	38	AF294	High Temperature Protector
Thor Freestanding Fryer	39		Frame Bottom F
Thor Freestanding Fryer	40		High Protection Box
Thor Freestanding Fryer	41	AF293	Igniter
Thor Freestanding Fryer	42		Door Shaft Assembly
Thor Freestanding Fryer	43		Badge Holder
Thor Freestanding Fryer	44	AF037	Fixed Castor
Thor Freestanding Fryer	45	AF265	Standard Castor