

Exploded diagram and spare parts list L537, L553, L554 & L555

For machines with digital timer:


[Click here](#)

For machines without digital timer:














[Click here](#)

Exploded diagram and spare parts list L537, L553, L554 & L555

For machines with digital timer:




Exploded diagram and spare parts list L537, L553, L554 & L555














Machine	Explode	Code	Description
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	1		Top Cover
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	2	N483	main Handle
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	3		Mica Plate
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	4		Rear Cover
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	5	AD582	Heating Element Upper
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	6		Cast Plate Upper
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	7		Cast Plate Lower
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	8		Hinge
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	9	N480	Plate Connecting Spring
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	10	AD583	Heating Element Lower
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	11		Insulation Plate Lower
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	12	N126	Thermal Cut Out
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	13		Main Body
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	14		Plug & Lead
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	15		Ceramic Tube
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	16		Mica Plate
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	17		Base Plate
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	18	AC689	Feet
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	19	N125	Thermostat
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	20	N129	Dial
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	21	N486	Indicator Light
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	22	N146	Switch
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	23	N271	Drip Tray
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	24	N484	Small Handle
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	25		Insulation Plate Upper
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	26	AD566	Tension Bracket
Double Contact Grills: L537-B L553-B L554-B & L555-B with timer	27	AE837	Timer with Transformer

Exploded diagram and spare parts list L537, L553, L554 & L555

For machines without digital timer:



Exploded diagram and spare parts list L537, L553, L554 & L555

Machine	Explode	Code	Description
Double Contact Grills: L537 L553 L554 & L555	1		Top Cover
Double Contact Grills: L537 L553 L554 & L555	2	N483	main Handle
Double Contact Grills: L537 L553 L554 & L555	3		Mica Plate
Double Contact Grills: L537 L553 L554 & L555	4		Rear Cover
Double Contact Grills: L537 L553 L554 & L555	5	AD582	Heating Element Upper
Double Contact Grills: L537 L553 L554 & L555	6		Cast Plate Upper
Double Contact Grills: L537 L553 L554 & L555	7		Cast Plate Lower
Double Contact Grills: L537 L553 L554 & L555	8		Hinge
Double Contact Grills: L537 L553 L554 & L555	9	N480	Plate Connecting Spring
Double Contact Grills: L537 L553 L554 & L555	10	AD583	Heating Element Lower
Double Contact Grills: L537 L553 L554 & L555	11		Insulation Plate Lower
Double Contact Grills: L537 L553 L554 & L555	12	N126	Thermal Cutout
Double Contact Grills: L537 L553 L554 & L555	13		Main Body
Double Contact Grills: L537 L553 L554 & L555	14		Plug & Lead
Double Contact Grills: L537 L553 L554 & L555	15		Ceramic Tube
Double Contact Grills: L537 L553 L554 & L555	16		Base Plate
Double Contact Grills: L537 L553 L554 & L555	17	AC689	Feet
Double Contact Grills: L537 L553 L554 & L555	18	N125	Thermostat
Double Contact Grills: L537 L553 L554 & L555	19	N129	Dial
Double Contact Grills: L537 L553 L554 & L555	20	N486	Indicator Light
Double Contact Grills: L537 L553 L554 & L555	21	N146	Switch
Double Contact Grills: L537 L553 L554 & L555	22	N271	Drip Tray
Double Contact Grills: L537 L553 L554 & L555	23		Mica Plate
Double Contact Grills: L537 L553 L554 & L555	24	N484	Small Handle
Double Contact Grills: L537 L553 L554 & L555	25		Insulation Clamp Upper