




Machine	Explode	Code	Description
CF619 – K25	8	AD816	On Button MINIGN K25 MULTIGN
CF619 – K25	9	AD817	Off Button MINIGN K25 MULTIGN
CF619 – K25	10		Body
CF619 – K25	11		Lipped Seal
CF619 – K25	12		Motor support
CF619 – K25	13		Earth terminal
CF619 – K25	14	AD806	Power card: TR2S MINIGN K25 K45 (Var) MULTIGN
CF619 – K25	15		UK power supply cable
CF619 – K25	16		Grommet
CF619 – K25	17		Screw Pt (Set x 10)
CF619 – K25	18		Foot set x 4
CF619 – K25	19	See S6	Casing
CF619 – K25	20	See S5	Motor
CF619 – K25	21	AD808	10mf Run capacitor: TR2S K25 MULTIGN
CF619 – K25	22	AD823	Start relay 192: K25 MULTIGN
CF619 – K25	23	AD807	90mf Start capacitor: TR2S K25 MULTIGN
CF619 – K25	24		Yoke 100x18 set x 5
CF619 – K25	25		Screw Shc M5x6 set x 10
CF619 – K25	26		Screw Hm6x12 stainless steel (set x 10) Set on washers CS L6 s(et x 10)
CF619 – K25	27		Motor shaft
CF619 – K25	36		Proximity detector
CF619 – K25	37		Plastic bowl
CF619 – K25	38		Rotor
CF619 – K25	39		Magnet
CF619 – K25	40	See S9	Cutter cover
CF619 – K25	41		Standard control panel plate
CF619 – K25	42	AD822	Impulse button: K25
CF619 – K25	43		Screw C 3x16 set x 10 Washer M3 galvanised steel (set x 10) Washer AZ3 galvanised steel (set x 10) Nut HU M3 stainless steel (set x 10)
CF619 – K25	44		Screw PT WN 1442 K40/14 Set X10
CF619 – K25	45		Detector support
CF619 – K25	S4		Body Assembly
CF619 – K25	S5		Motor Assembly 1 230/240 50
CF619 – K25	S6		Casing Assembly
CF619 – K25	S7		Safety Support Assembly
CF619 – K25	S8		Plastic Cutter Equipment Stainless Steel Cutter Equipment
CF619 – K25	S9	AD821	Cutter cover assembly: K25 MULTIGN