



## Installation Instructions

### Silverlink 600 Floorstands

SLS3, SLS4, SLS6, SLS7, SLS9

Please make a note of your product details for future use:

Date Purchased: \_\_\_\_\_

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Dealer: \_\_\_\_\_

\_\_\_\_\_

**SILVERLINK 600**


## **FLOORSTANDS**

### **SLS3, SLS4, SLS6, SLS7, SLS9**

#### **IMPORTANT**

**PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THE EQUIPMENT. KEEP THEM IN A SAFE PLACE FOR FUTURE REFERENCE.**

1. Remove all protective plastic coating from the unit.
2. Screw feet to adjust until unit is level and at required height.
3. When fitting countertop units onto SLS stands, the feet should be located into the corresponding square holes in the angle supports with the two smaller round holes at one end of the angle signifying the rear of the base unit.
4. SLS6, SLS7 & SLS9 are supplied with a suiting channel (2 on SLS9) which enables multiple units to be mounted. These should be positioned to locate the feet of the units as with the angle supports, and can be fixed using the screws supplied if required.



5. Clean units regularly with hot water and detergent, do not use abrasive or chlorine based cleaners on stainless steel.

## **SERVICE INFORMATION**

Catering equipment should be routinely serviced to ensure a long and trouble free life. With this in mind it is recommended that appliances are serviced every six months by a competent engineer.

For help regarding the installation, maintenance and use of your Lincat equipment, please call:-

### **LINCAT SERVICE HELP DESK**

 **01522 875520**

### **AUTHORISED SERVICE AGENTS**

We recommend that all servicing, other than routine cleaning, is carried out by our authorised service agents and will accept no responsibility for work carried out by other persons. Note that for safe and efficient operation, appliances need regular servicing.

Please quote both the model and serial numbers from the data plate attached to the unit. Give brief details of the service requirement.

Lincat reserve the right to carry out any work under warranty during normal working hours, i.e. Monday to Friday, 8.30 a.m. - 5.00 p.m.

### **CONDITIONS OF GUARANTEE**

The guarantee does not cover: -

1. Accidental breakage or damage
2. Operational misuse, wear and tear from normal usage, incorrect adjustment and neglect.
3. Incorrect installation, maintenance, modification or unauthorised service work.