



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 1 of 6

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

- INSTALLATION INSTRUCTIONS
 - SAFETY INSTRUCTIONS
 - USER INSTRUCTIONS

HOB UNITS

MODEL: P2H

MODEL: P4H

MODEL: 1871

MODEL: CHU

MODEL: CHU2

MODEL: CHUB



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 2 of 6

TELEPHONE: SERVICE (44) 01332 875665

FAX: SERVICE (44) 01332 875536

PLEASE NOTE INSTALLATION OF THIS UNIT MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN

IMPORTANT

Please read these instructions before you attempt to use the equipment. Keep these instructions for future reference.

WARNING

To avoid scratching the highly polished exterior surface of this equipment whilst in transit, the protective film on the exterior surfaces has NOT been removed.

It is IMPORTANT that this protective film is peeled off before the equipment is used.

WARNING

1. All electrical appliances/parts must be earthed.
2. No user-serviceable parts.
3. Isolate power supply before carrying out any installation work.

INSTALLATION

1. Choose a suitable site for your machine taking into consideration its, use, and any heat that may be generated whilst in service.
2. Remove all protect film and packing material, and inspect for any damage which may effect the machine's electrical safety.
3. All appliances with an electrical loading above 3 kilowatts must be connected to a suitable supply by qualified electrician, who should ensure that
 - a) Precaution is taken during installation regarding leakage current,
 - b) The means of isolation has a contact separation of at least 3mm on all poles, and
 - c) It is installed in accordance with Health and Safety at Work Act, BS Codes of Practice, IEE Wiring Regulations and Building and Local Authority Standards.



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 3 of 6

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

OPERATING

CHU, CHU2 & CHUB

1. Ensure all controls are in the off position, then switch on at the power supply, the red lamp will indicate that the power is on.
2. Turn the appropriate energy regulator to the required setting, number 3 for boiling and reduce the setting to simmer.
3. Chub only for operating the bain marie it can be used either wet or dry. To use wet place some water in the enamelled pot and turn on

P2H, P4H AND 1871

1. Ensure all controls are in the off position, then turn on the power supply
2. Turn the appropriate energy regulator to the desired setting 3 for boiling and reduce to simmer, the red lamp for that particular hob will illuminate to indicate that there is power to the hob and that the hob is on.

FOR MAXIMUM EFFICIENCY USE GOOD QUALITY PANS OF THE CORRECT SIZE, AS TOTAL COVERAGE OF THE PLATE ENSURES ANY SPILLAGE WILL FLOW EASILY

CLEANING

It must be accepted that due to the heat involved the outer rings may taint and this will not be able to be removed although this can be reduced by not having the hobs on full power for prolonged periods.

Use hot soapy water or a non abrasive hob cleaner

Before cleaning any unit, and before working on any electrical equipment, **DISCONNECT FROM THE ELECTRICITY SUPPLY.** If the appliance is permanently connected, switch off the mains supply. The control panel or body containing the electrical fixtures must not be immersed in water, and the appliance must not be cleaned by using water jets. All other parts are easily removable for cleaning. All units give best results if kept clean.



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 4 of 6

TELEPHONE: SERVICE (44) 01332 875665

FAX: SERVICE (44) 01332 875536

FAULT FINDING

The most common fault is that the unit is not connected to the mains supply, and so the mains lamp will not illuminate, in this circumstance please try the following before calling for service assistance

1. Check the unit is plugged into the mains supply and the socket is switched on
2. Check the fuse in the plug
3. Try a different socket
4. If the unit has been permanently connected to a fused switch ask a qualified electrician or competent person to check the connections

One of the above may cure your fault, if not contact your distributor.

RATING – CHU 1.5KW 6.25A 240V, CHUB 1.6KW 7A 240V
P2H, CHU2 3KW 12.5A 240V
P4H, 7KW 30A 1~, 12.5,8,8A 3~N
1871, 7KW 30A 1~, 12.5,8,8A 3~N



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 5 of 6

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

Declaration of conformity CE

- This product has been designed, constructed and marketed in compliance with:
 - safety requirements of EEC Directive “Gas” 90/396;
 - safety requirements of EEC Directive “Low voltage” 73/23;
 - protection requirements of EEC Directive 93/68.
- This product is suitable for contact with foodstuffs, and complies with EEC Directive 89/109.
- This product has been designed to be used only for cooking. Any other use (such as heating a room) is improper and dangerous.
- This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.
- A symbol on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



INSTRUCTION REF: IN119

ISSUE No. 2

DATE 06.03.09

Page 6 of 6

TELEPHONE: SERVICE (44) 01332 875665

FAX: SERVICE (44) 01332 875536

Parry Catering recognises our obligations to the EU DIRECTIVE covering the waste disposal of electrical and electronic equipment (WEEE), Parry Catering are committed to this policy in order to help conserve the environment.

At the end of this unit's life you **MUST** dispose of it in an approved manner. You **MUST** not discard the unit or place it in the refuse bin.

You have several options:

- a) Take the unit to an approved WEEE scheme company, there will be one in your area.
- b) Take the unit to an approved waste disposal site; many sites are managed by your local authority.
- c) Contact the unit's manufacturer, importer or their agent the contact details will be on the unit.

There will probably be a charge for this service which will depend on the physical location of the unit and size you will be given a collection price for a curb side collection based on commercial rates prevailing at the time.

It should be noted that the unit to be collected should be suitably packed and sealed to prevent dangerous gases and fluids from escaping. The condition of the unit must also be clean to comply with health and safety regulations.